

1. Place one small black washer (1) onto the threaded part of the spigot.
2. Insert thread (3) of spigot through the hole in the side of the lower chamber of your Berkey® system.
3. Place the second small black washer (2) over the thread that is now inside the chamber and secure in place with the nut (4).
4. Tighten securely by hand only.

